

Din-T MCB accessories


Mounting of add-on devices on MCBs, RCCBs, RCBOs and isolating switches

Type	Description	Din-T6	Din-T10	Din-T10H	Din-T15	Din-T DC	DSRCD all types	DSRCM	DINTMS	Change-over switch
DTAUXAL	Signal or auxiliary contact	L - R	L - R	-	L - R	L - R	R	R	L - R	L - R
DTAUXALG	Signal or auxiliary contact, gold contact	L - R	L - R	-	L - R	L - R	R	R	L - R	L - R
DINT10HHS	Signal or auxiliary + auxiliary contact	-	-	R	-	-	-	-	-	R
DTPBS	Panelboard switch	L - R	L - R	-	L - R	L - R	R	-	-	-
DINTSHT	Shunt trip	-	-	L	-	-	-	-	-	-
DTSHT	Shunt trip	L - R	L - R	-	L - R	L - R	R	R	-	-
DTUVT	Undervoltage release	L - R	L - R	-	L - R	L - R	R	R	-	-
DTMD	Motor operator	L - R	L - R	-	L - R	L - R	R	R	-	-

L = Left mounting R = Right mounting


Miniature circuit breakers ¹⁾

Din-T 6, 10, 15, DC, E6
(Not for Din-T10H)




Residual current circuit breakers (RCCB)

Din-Safe safety switches (DSRCD)



Residual current circuit breakers (RCBO) with overcurrent protection

Din-Safe (DSRCB)




Residual current circuit breakers (RCBO) with overcurrent protection

Din-Safe (DSRCBS)


Miniature circuit breakers with add-on earth leakage module

Din-Safe-M (DSRCM)



Isolating switches

Din-T (DINTMS)



Notes: ¹⁾ For Din-T10H accessories refer Din-T10H 1 - 20.

²⁾ First auxiliary must be DSRCBSAX type.

DSRCBH - single pole RCD/MCB will not accept side mounted accessories.

DINTMS - Main switches will accept side mounting auxiliary contacts only.